

# X-RANGE ENQUIRY MODE MENU

## Enquiry Mode Menu:

Press 2 for x 2 seconds the spanner to access the info menu

Scroll through the menu using the **—** or **+** symbols.

- A. Ionisation current (micro amps  $\mu$ )
- B. DHW flow (L/Min)
- C. CH Pressure (bar)
- E. Last received RF message
- F. Fan Speed (RPM)
- P. Pump speed (RPM)
- T. Last fault code
- = Main firmware version
- ≡ dsp Processor software version
- 0. Heat exchanger sensor S0 (°C)
- 1. Flow temperature sensor S1 (°C)
- 2. Return Sensor S2 (°C) – Not applicable ICx
- 3. DHW Sensor S3 (°C)
- 4. Sensor cold tap water S4 (°C) – Not applicable ICx
- 5. Sensor flue gas S5 (°C)
- 6. Outdoor sensor S6 (°C) – Not applicable ICx
- 7. Cylinder Sensor S7 (°C) – Not applicable ICx